

Place Smart Screen™ panel over gutter, lining up front edge of panel with front of gutter lip. Back edge should rest on drip-edge.

Zip screw front edge of Smart Screen™ panel to top of gutter lip using pre-set fastening points. When necessary, it is possible to attach panels without using pre-set fastening points by zip screwing directly down through the round edge on the lip of panel. Take care not to over-tighten the screw which will crush the lip and cause a run-off point.

Using hand pressure, push down back of Smart Screen™ panel against drip-edge until panel is level. Secure back portion of panel using 2-3 zip screws to drip-edge. This will significantly strengthen the overall gutter system.

OUTSIDE CORNERS

Cut first panel on 45° angle. Cut second panel of Smart Screen™ on 45° angle as well, leaving a tab through which you can secure the mitered panels together.

INSIDE CORNERS

Run your first panel of Smart Screen™ to the back of the gutter completely covering the inside miter portion of the gutter. Trim out appropriate portion of the front lip of the next panel so that it can overlap first panel. Zip screw two overlapping sections together. When necessary, fashion small splash guard on top of the overlapping sections.

